BALLUFF

BIS U-6028-048-104-06-ST28 PROFINET BIS U-6028-048-114-06-ST28 PROFINET BIS U-6028-048-124-06-ST28 PROFINET BIS U-6028-048-134-06-ST28 PROFINET BIS U-6028-048-104-06-ST22 PROFINET Technical Description, Operating Manual



english

www.balluff.com

Obser instructions 4 1.1 About this manual 4 1.2 Typographical conventions 4 1.3 Symbols 4 1.4 Abbreviations 4 2 Safety 5 2.1 Intended use 5 2.2 Meaning of the warning notes 5 2.3 General safety notes 5 2.4 Conformity 6 3 Basic knowledge 7 3.1 Function principle of identification systems 7 3.2 Product description 7 3.4 Data integrity 8 3.5 Bus connection 8 4 Installation 9 4.1 Scope of delivery of the processor 9 4.2 Processor installation 9 4.3 Interface information/wiring diagrams 10 5 Technical data 12 6 Bus connection 16 6.1 Project planning 16 6.2 Device name and IP address 16 <th></th> <th>Llock inclusions</th> <th>1</th>		Llock inclusions	1
1.1 About this manual 4 1.2 Typographical conventions 4 1.3 Symbols 4 1.4 Abbreviations 4 2 Safety 5 2.1 Intended use 5 2.2 Meaning of the warning notes 5 2.3 General safety notes 5 2.4 Conformity 6 3 Basic knowledge 7 3.1 Function principle of identification systems 7 3.2 Product description 7 3.3 Control function 8 3.4 Data integrity 8 3.5 Bus connection 8 4.1 Scope of delivery of the processor 9 4.1 Scope of delivery of the processor 9 4.1 Scope of delivery of the processor 9 4.1 Scope of delivery of the processor 10 5 Technical data 12 6 Bus connection 16 6.1 Project planning 16 6.2 <t< td=""><td></td><td>Oser instructions</td><td>4</td></t<>		Oser instructions	4
1.2 Typographical conventions 4 1.3 Symbols 4 1.4 Abbreviations 4 2 Safety 5 2.1 Intended use 5 2.2 Meaning of the warning notes 5 2.3 General safety notes 5 2.4 Conformity 6 3 Basic knowledge 7 3.1 Function principle of identification systems 7 3.2 Product description 7 3.3 Control function 8 3.4 Data integrity 8 3.5 Bus connection 8 4.1 Scope of delivery of the processor 9 4.2 Processor installation 9 4.3 Interface information/wiring diagrams 10 5 Technical data 12 6 Bus connection 16 6.1 Project planning 16 6.2 Device name and IP address 16 7 Configuring the processor 17 7.1 BUS par		1.1 About this manual	4
1.3 Symbols 4 1.4 Abbreviations 4 2 Safety 5 2.1 Intended use 5 2.2 Meaning of the warning notes 5 2.3 General safety notes 5 2.4 Conformity 6 3 Basic knowledge 7 3.1 Function principle of identification systems 7 3.2 Product description 7 3.3 Control function 8 3.4 Data integrity 8 3.5 Bus connection 8 4 Installation 9 4.1 Scope of delivery of the processor 9 4.2 Processor installation 9 4.3 Interface information/wiring diagrams 10 5 Technical data 12 6 Bus connection 16 6.1 Project planning 16 6.2 Device name and IP address 17 7 Configuring the processor 17 7.1 BUS parameters		1.2 Typographical conventions	4
1.4 Abbreviations 4 2 Safety 5 2.1 Intended use 5 2.2 Meaning of the warning notes 5 2.3 General safety notes 5 2.4 Conformity 6 3 Basic knowledge 7 3.1 Function principle of identification systems 7 3.2 Product description 7 3.3 Control function 8 3.4 Data integrity 8 3.5 Bus connection 8 4 Installation 9 4.1 Scope of delivery of the processor 9 4.2 Processor installation 9 4.3 Interface information/wiring diagrams 10 5 Technical data 12 6 Bus connection 16 6.1 Project planning 16 6.2 Device name and IP address 17 7.1 BUS parameters 17 7.2 Applications parameters 19 8 Device function 27 8.1 Function principle of the BIS U-6028 27 8.2 Function indicators 42 8.3 Examples 44		1.3 Symbols	4
2Safety52.1Intended use52.2Meaning of the warning notes52.3General safety notes52.4Conformity63Basic knowledge73.1Function principle of identification systems73.2Product description73.3Control function83.4Data integrity83.5Bus connection84Installation94.1Scope of delivery of the processor94.2Processor installation94.3Interface information/wiring diagrams105Technical data126Bus connection166.1Project planning166.2Device name and IP address177.1BUS parameters177.2Applications parameters198Device function278.1Function principle of the BIS U-6028278.3Examples44	_	1.4 Addreviations	4
2.1Intended use52.2Meaning of the warning notes52.3General safety notes52.4Conformity63Basic knowledge73.1Function principle of identification systems73.2Product description73.3Control function83.4Data integrity83.5Bus connection84Installation94.1Scope of delivery of the processor94.2Processor installation94.3Interface information/wiring diagrams105Technical data126Bus connection166.1Project planning166.2Device name and IP address167Configuring the processor177.1BUS parameters177.2Applications parameters198Device function278.1Function principle of the BIS U-6028278.2Function indicators428.3Examples44	2	Safety	5
2.2 Meaning of the warning notes 5 2.3 General safety notes 5 2.4 Conformity 6 3 Basic knowledge 7 3.1 Function principle of identification systems 7 3.2 Product description 7 3.3 Control function 8 3.4 Data integrity 8 3.5 Bus connection 8 4.1 Scope of delivery of the processor 9 4.2 Processor installation 9 4.3 Interface information/wiring diagrams 10 5 Technical data 12 6 Bus connection 16 6.1 Project planning 16 6.2 Device name and IP address 16 7 Configuring the processor 17 7.1 BUS parameters 17 7.2 Applications parameters 19 8 Device function 27 8.1 Function principle of the BIS U-6028 27 8.2 Function indicators 42 </td <td></td> <td>2.1 Intended use</td> <td>5</td>		2.1 Intended use	5
2.3General safety notes52.4Conformity63Basic knowledge73.1Function principle of identification systems73.2Product description73.3Control function83.4Data integrity83.5Bus connection84Installation94.1Scope of delivery of the processor94.2Processor installation94.3Interface information/wiring diagrams105Technical data126Bus connection166.1Project planning166.2Device name and IP address167Configuring the processor177.1BUS parameters177.2Applications parameters198Device function278.1Function principle of the BIS U-6028278.2Function indicators428.3Examples44		2.2 Meaning of the warning notes	5
2.4Conformity63Basic knowledge73.1Function principle of identification systems73.2Product description73.3Control function83.4Data integrity83.5Bus connection84Installation94.1Scope of delivery of the processor94.2Processor installation94.3Interface information/wiring diagrams105Technical data126Bus connection166.1Project planning166.2Device name and IP address167Configuring the processor177.1BUS parameters177.2Applications parameters198Device function278.1Function principle of the BIS U-6028278.2Function indicators428.3Examples44		2.3 General safety notes	5
3Basic knowledge73.1Function principle of identification systems73.2Product description73.3Control function83.4Data integrity83.5Bus connection84Installation94.1Scope of delivery of the processor94.2Processor installation94.3Interface information/wiring diagrams105Technical data126Bus connection166.1Project planning166.2Device name and IP address177.1BUS parameters177.2Applications parameters198Device function278.1Function principle of the BIS U-6028278.2Function indicators428.3Examples44		2.4 Conformity	6
3.1Function principle of identification systems73.2Product description73.3Control function83.4Data integrity83.5Bus connection84Installation94.1Scope of delivery of the processor94.2Processor installation94.3Interface information/wiring diagrams105Technical data126Bus connection166.1Project planning166.2Device name and IP address177.1BUS parameters177.2Applications parameters198Device function278.1Function principle of the BIS U-6028278.2Function indicators428.3Examples44	3	Basic knowledge	7
3.2 Product description 7 3.3 Control function 8 3.4 Data integrity 8 3.5 Bus connection 8 4.1 Scope of delivery of the processor 9 4.2 Processor installation 9 4.3 Interface information/wiring diagrams 10 5 Technical data 12 6 Bus connection 16 6.1 Project planning 16 6.2 Device name and IP address 16 7 Configuring the processor 17 7.1 BUS parameters 17 7.2 Applications parameters 19 8 Device function 27 8.1 Function principle of the BIS U-6028 27 8.2 Function indicators 42 8.3 Examples 44		3.1 Function principle of identification syste	ms 7
3.3Control function83.4Data integrity83.5Bus connection84Installation94.1Scope of delivery of the processor94.2Processor installation94.3Interface information/wiring diagrams105Technical data126Bus connection166.1Project planning166.1Project planning166.2Device name and IP address167Configuring the processor177.1BUS parameters177.2Applications parameters198Device function278.1Function principle of the BIS U-6028278.2Function indicators428.3Examples44		3.2 Product description	7
3.4 Data integrity 8 3.5 Bus connection 8 4 Installation 9 4.1 Scope of delivery of the processor 9 4.2 Processor installation 9 4.3 Interface information/wiring diagrams 10 5 Technical data 12 6 Bus connection 16 6.1 Project planning 16 6.2 Device name and IP address 16 7 Configuring the processor 17 7.1 BUS parameters 17 7.2 Applications parameters 19 8 Device function 27 8.1 Function principle of the BIS U-6028 27 8.2 Function indicators 42 8.3 Examples 44		3.3 Control function	8
3.5 Bus connection84Installation94.1 Scope of delivery of the processor94.2 Processor installation94.3 Interface information/wiring diagrams105Technical data126Bus connection166.1 Project planning166.2 Device name and IP address167Configuring the processor177.1 BUS parameters177.2 Applications parameters198Device function278.1 Function principle of the BIS U-6028278.2 Function indicators428.3 Examples44		3.4 Data integrity	8
4Installation94.1Scope of delivery of the processor94.2Processor installation94.3Interface information/wiring diagrams105Technical data126Bus connection166.1Project planning166.2Device name and IP address167Configuring the processor177.1BUS parameters177.2Applications parameters198Device function278.1Function principle of the BIS U-6028278.3Examples44		3.5 Bus connection	8
4.1Scope of delivery of the processor94.2Processor installation94.3Interface information/wiring diagrams105Technical data126Bus connection166.1Project planning166.2Device name and IP address167Configuring the processor177.1BUS parameters177.2Applications parameters198Device function278.1Function principle of the BIS U-6028278.3Examples44	4	Installation	9
4.2Processor installation94.3Interface information/wiring diagrams105Technical data126Bus connection166.1Project planning166.2Device name and IP address167Configuring the processor177.1BUS parameters177.2Applications parameters198Device function278.1Function principle of the BIS U-6028278.2Function indicators428.3Examples44		4.1 Scope of delivery of the processor	9
4.3 Interface information/wiring diagrams105 Technical data126 Bus connection166.1 Project planning166.2 Device name and IP address167 Configuring the processor177.1 BUS parameters177.2 Applications parameters198 Device function278.1 Function principle of the BIS U-6028278.2 Function indicators428.3 Examples44		4.2 Processor installation	9
5Technical data126Bus connection166.1Project planning166.2Device name and IP address167Configuring the processor177.1BUS parameters177.2Applications parameters198Device function278.1Function principle of the BIS U-6028278.2Function indicators428.3Examples44		4.3 Interface information/wiring diagrams	10
Bus connection 166.1 Project planning166.2 Device name and IP address167 Configuring the processor177.1 BUS parameters177.2 Applications parameters198 Device function278.1 Function principle of the BIS U-6028278.2 Function indicators428.3 Examples44	5	Technical data	12
Bus connection 166.1Project planning166.2Device name and IP address16 7Configuring the processor 177.1BUS parameters177.2Applications parameters19 8Device function27 8.1Function principle of the BIS U-6028278.2Function indicators428.3Examples44			
6.1Project planning166.2Device name and IP address167Configuring the processor177.1BUS parameters177.2Applications parameters198Device function278.1Function principle of the BIS U-6028278.2Function indicators428.3Examples44	6	Bus connection	16
6.2 Device name and IP address167Configuring the processor177.1BUS parameters177.2Applications parameters193Device function278.1Function principle of the BIS U-6028278.2Function indicators428.3Examples44		6.1 Project planning	16
7Configuring the processor177.1BUS parameters177.2Applications parameters198Device function278.1Function principle of the BIS U-6028278.2Function indicators428.3Examples44		6.2 Device name and IP address	16
7.1BUS parameters177.2Applications parameters193Device function278.1Function principle of the BIS U-6028278.2Function indicators428.3Examples44	7	Configuring the processor	17
7.2 Applications parameters198 Device function278.1 Function principle of the BIS U-6028278.2 Function indicators428.3 Examples44		7.1 BUS parameters	17
Device function278.1Function principle of the BIS U-6028278.2Function indicators428.3Examples44		7.2 Applications parameters	19
8.1Function principle of the BIS U-6028278.2Function indicators428.3Examples44	8	Device function	27
8.2Function indicators428.3Examples44		8.1 Function principle of the BIS U-6028	27
8.3 Examples 44		8.2 Function indicators	42
		8.3 Examples	44
Appendix 53		Appendix	53_

User instructions

1.1	About this manual	This manual describes the processor for the BIS U-6028 identification systems and startup instructions for immediate operation.					
1.2 Typographical The following conventions are used in this manual conventions			inual.				
	Enumerations	Enumerati – Entry ⁻ – Entry 2	Enumerations are shown as a list with an en-dash. - Entry 1, - Entry 2.				
	Actions	 Action instantantantantantantantantantantantantant	tructions are indicated by a precedin instruction 1. tion result. instruction 2.	ng triangle. Th	e result of an action is indicated by		
	Syntax	Numbers – Decim – Hexad	l umbers: Decimal numbers are shown without additional indicators (e.g. 123), Hexadecimal numbers are shown with the additional indicator _{hex} (e.g. 00 _{hex}).				
		Parameter Parameter	e rs: 's are shown in italics (e.g. <i>Dynamic</i>	c).			
		Directory Reference (e.g. PROJE	Directory paths: References to paths where data is stored or to be saved are shown in small caps (e.g. Project:\Data Types\User Defined).				
Control characters: Control characters for sending are set			haracters: haracters for sending are set in angle	e brackets (e.ç	g. <ack>)</ack>		
		ASCII con Character	de: s sent in ASCII code are set in apos	strophes (e.g. '	'L').		
1.3	Symbols	S Caution! This symbol indicates a safety instruction that must be followed without except		st be followed without exception.			
		<u>î</u>	Note, tip This symbol indicates general notes).			
1.4	Abbreviations	BIS CRC DCP EEPROM EIRP EMC EPC™ ERP FCC	Balluff Identification System Cyclic Redundancy Check Discovery and basic Configuration Protocol Electrical Erasable and Programmable ROM Equivalent Isotropically Radiated Power Electromagnetic Compatibility Electronic Product Code Effective Radiated Power Federal Communications	IP LBT LF CR MAC n.c. PC PNO PLC Tag TID	Internet Protocol Listen Before Talk Line Feed with Carriage Return Media Access Control not connected Personal Computer PROFIBUS Nutzerorganisation e.V. Programmable Logic Controller Data carrier with antenna		
			Commission	UHF	Ultra-high frequency		

GSD

GSDML IC

General Station Description GSD Markup Language Industry Canada

2 Safety

2.1 Intended use	The BIS U-6028 processor is a component of the BIS U identification system. Within the identification system, it is used to connect to a higher-level controller (PLC, PC); it may only be used in the industrial sector.
	 For operation within the European Community BIS U-6028-048-104-06-ST22 BIS U-6028-048-104-06-ST28 For operation in the USA, Canada BIS U-6028-048-114-06-ST28 For operation in China BIS U-6028-048-124-06-ST28 For operation in Brazil BIS U-6028-048-134-06-ST28
2.2 Meaning of the warning notes	 Caution! The pictogram used with the word "Caution" warns of a situation that could harm someone's health or damage equipment. Failure to observe these warning notes may result in injury or damage to equipment. Always observe the described measures for preventing this danger.
2.3 General safety notes	 Caution! This UHF system consists of a processor and antennas according to specifications and may only be operated within the specified countries subject to all applicable national legal regulations and standards. When using the UHF system in the European Community, the provisions in ETSI standard EN 302 208 apply. When using the UHF system in the USA, the directives of FCC, Part 15, apply. When using the UHF system in Canada, the directives of IC, RSS-210 apply. When using the UHF system in Brazil, the directives of ANATEL, 506/2008 and 442/2006 apply.

Installation and startup

Installation and startup are to be performed by trained technical personnel only. Any damage resulting from unauthorized manipulation or improper use voids the manufacturer's guarantee and liability claims against the manufacturer. When connecting the processor to an external controller, observe proper selection and polarity of the connection as well as the power supply (see "Installation" on page 9).

The processor may only be used with approved power supplies (see "Technical data" on page 12).

Safety



Caution!

The antennas of the BIS U identification system transmit ultra-high frequency electromagnetic waves.

IEC 62369 stipulates that personnel may not remain within close range of the UHF antenna for long periods (several hours).

For operation within the European Community:

When selecting the installation location for the processor, make sure that the minimum distance between the UHF antenna and the workplace is 26 cm.

The radiated power must not exceed the maximum permitted limit values:

- 0.5 watt_{ERP} for antennas with an opening angle $> 70^{\circ}$,
- 2.0 watt_{ERP} for antennas with an opening angle \leq 70°.

For operation in the USA, Canada and Brazil:

When selecting the installation location for the processor, make sure that the minimum distance between the UHF antenna and the workplace is 30 cm. The radiated power must not exceed the permissible limit value of 4 watt_{\mbox{\tiny EIRP}}



Note

See the "Basic UHF manual" for more information on minimum/maximum clearance distances and antenna power.

2.4 Conformity

BIS U-6028-048-104-06-ST22, BIS U-6028-048-104-06-ST28

This product was developed and manufactured in accordance with all applicable CE European Directives. CE conformity has been verified.

Additional radio interference suppression for BIS U-6028-048-104-06-ST22:

When installing the device, power supply cables need adequate measures for radio interference suppression to ensure compliance to the limits defined in EN 55022. This is achieved by installing 3 pieces of snap ferrite "Würth No. 7427151" close to the device or by means of equivalent measures.

BIS U-6028-048-114-06-ST28



The product was developed and manufactured in accordance with the directives applicable in the USA and Canada. Conformity has been verified.

BIS U-6028-048-124-06-ST28

CMIIT-ID 2014DJ1522

The product was developed and manufactured in accordance with the directives applicable in China. Conformity has been verified.

BIS U-6028-048-134-06-ST28



i

The product was developed and manufactured in accordance with the directives applicable in Brazil. Conformity has been verified.

When using BIS U-6028-048-134-06-ST28 power supply has to be connected via "BIS Power supply FILTER" included in the sales package.

Basic knowledge

All approvals and certifications are no longer valid if:

- Components are used that are not part of the BIS U identification system
- Components are used that have not been explicitly approved by Balluff. _

Operation and testing

The operator is responsible for ensuring that local safety regulations are observed. If defects and persistent faults occur in the identification system, take it out of service and secure against unauthorized use.

3.1 Function principle of identification systems

The BIS U identification system is classified as a non-contacting system with read and write unction, which not only allows it to detect information programmed permanently in the data carrier, but also to collect and pass on current information.

Main components of BIS U identification systems include:

- Processor
- Antennas
- Data carriers



Fig. 1: System overview

- 1 PC
- 2 PLC
- 3 Connection to the host system
- 4 Processor

- 5 Antenna cable
- Antennas (max. 4) 6
- 7 Data carriers

The main areas of application are:

- In the production and control of material flow (e.g. in variant-specific processes, workpiece transport in conveying systems, for acquiring safety-relevant data)
- In tool coding and monitoring
- In process equipment organization
- In warehousing for monitoring material movements _
- In transporting and conveying _
- _ in waste disposal for quantity-based fee assessment



See the "Basic UHF manual" for more information on UHF identification systems.

Basic knowledge

3.2	Product description	 UHF-RFID (Operating frequencies see "Operating frequency and radiated power" on page 14) Read/write distance typically up to 6 m depending on ambient conditions and installed system components such as antennas, data carriers, cables, etc. Connection option for 4 antennas Standard interface: 2 × PROFINET Service interface: 1 × RS232 Rugged metal housing Control displays for communication and status Data carrier types according to ISO 18000-6 type C or EPCglobal[™] Class 1 Generation 2
3.3	Control function	 The processor is the link between data carrier and controlling system. It manages two-way data transfer between data carrier and antenna and provides buffer storage. The processor uses the antenna to write data from the controlling system to the data carrier or reads the data from the data carrier and makes it available to the controlling system. Host systems may be the following: a control computer (e.g. industrial PC), a PLC. Double bit header for asynchronous data transmission: If a controller does not synchronously send the data range for updating the input/output buffer, data inconsistencies may occur when sending more than two bytes. Consistency of the sent data can then only be ensured by sending the control bits in the first byte and again in the last bytes of the input/output buffer. By comparing the two bit headers, it can be determined whether the data is fully updated and can be accepted. This method affects neither the PLC cycle time nor the bus access time. Only one byte in the data buffer for the byte of the second bit header is required instead of using it for data.
3.4	Data integrity	In order to ensure data integrity, the data transfer between the data carrier and processor can be monitored using a CRC-16 data check.
3.5	Bus connection	Processor and controlling system are connected via PROFINET. The PROFINET IO (decentralized peripheral) is tailored to communication between a controller and decentralized field devices. PROFINET is a combination of ProfiBus DP and EtherNet in one system, whereby the IO view of ProfiBus is retained. The device model of PROFINET IO is also oriented towards the ProfiBus technology. The characteristics of the IO devices are, however, described by GSD files based on XML (GSDML); project planning/system integration is performed in the same way as for to ProfiBus devices. In a PROFIBUS network, IO controllers and IO devices are connected to each other using all common network topologies: star, line, ring or tree type topologies are possible. The BIS U-6028 has a built-in IRT switch with two ports for this purpose. This means that both RT and IRT can be used.

4 Installation

4.1 Scope of delivery of the processor

- Included in the scope of delivery:
- BIS U-6028
- 5x end caps
- Safety instructions

i Note

For corresponding technical documents as well as additional information on available software and accessories, see www.balluff.com.

4.2 Processor installation



Fig. 2: Installation



Caution!

BIS U-6028-048-134-06-ST28 PROFINET,

- The antennas for the BIS U identification system transmit ultra-high frequency electromagnetic waves!
- The installation position of the processor and antennas must guarantee a safety distance between the antennas and the workplaces of personnel. For safety distances, see Chapter 2 "Safety" beginning on page 5.

The read/write distance can typically be as great as 6 m depending on the ambient conditions and installed system components. See the "Basic UHF manual" for more information on minimum/maximum clearance distances.

- Select a suitable installation position.
- Secure the processor using four M5 screws (strength category 8.8, lightly oiled, tightening torque M = 5.2 Nm).

Note

Optional mounting plates are available for installing the processor (see Accessories on page 53).

Installation

4.3 Interface information/ wiring diagrams



Note Make the ground connection either directly or using an RC combination to ground.



Fig. 3: Electrical connection BIS U-6028-...-ST28

- 1 Antenna port 1
- 2 Antenna port 2
- **3** Antenna port 3
- 4 Antenna port 4
- **5** Function ground FE

- 6 X1 power supply
- 7 X2 PROFINET port 2
- 8 X3 PROFINET port 1
- **9** X4 service interface RS232

i Note

Not all antenna ports 1...4 have to be connected.

X1 - power supply



Function
0 V
0 V
FE
+24 V DC
+24 V DC

X2/X3 – PROFINET port 1 / port 2

3	
Z	

/4	PIN	Function
)	1	TD+
	2	RD+
/	3	TD-
.1	4	RD-

X4 - service interface RS232



3 PIN Eunction	
1 n.c.	
2 TxD	
3 GND	
4 RxD	

Installation

Δ



1 Antenna port 1

i

- 2 Antenna port 2
- **3** Antenna port 3
- 4 Antenna port 4
- 5 Function ground FE

- 7 X2 PROFINET port 2
- 8 X3 PROFINET port 1
- 9 X4 service interface RS232

Note i

Not all antenna ports 1...4 have to be connected.

X1 - power supply

$\overline{)}$

\sim	PIN	Function
	1	+24 V DC
<u>.</u>	2	0 V
2	3	n. c.
\searrow	4	n. c.
-	5	FE

X2/X3 – PROFINET port 1 / port 2



PIN	Function
1	TD+
2	TD-
3	RD+
4	n. c.
5	n. c.
6	RD-
7	n. c.
8	n. c.



4 3	PIN	Function
	1	n.c.
	2	TxD
	3	GND
17 2	4	RxD

www.balluff.com

5 Technical data

Dimensions BIS U-...-ST28



Fig. 5: Dimensions (in mm)

Mechanical data BIS U-...-ST28

Housing material	Profiled housing and frame made from coated steel	
X1 - power supply	V _s 24 V DC, panel connector 7/8", 5-pin	
X2 – PROFINET port 2	M12 panel socket, 4-pin, D-coded	
X3 – PROFINET port 1	M12 panel socket, 4-pin, D-coded	
X4 – service port	Panel connector M12, 4-pin, A-coded	
Antenna ports 14	Antenna socket R-TNC	
Enclosure rating per IEC 60529	IP 65	
Weight	2100 g	

Technical data

Dimensions BIS U-...-ST22

> 00 O 59,8 107,6 20 54 20 Q 8¢\$ 品名 ۲ M5 BIS U-6028 338 352 42,7 M5 88 31,2 24,2 24,2 38 w

3x26

Fig. 6: Dimensions (in mm)

Mechanical data BIS U-...-ST22

Housing material	Profiled housing and frame made from coated steel	
X1 - power supply	$\rm V_s24~V~DC,~push-pull~power~connector$ (AIDA recommendation), 5-pin	
X2 – PROFINET port 2	RJ45 plug (AIDA recommendation)	
X3 – PROFINET port 1	RJ45 plug (AIDA recommendation)	
X4 – service port	Panel connector M12, 4-pin, A-coded	
Antenna ports 14	Antenna socket R-TNC	
Enclosure rating per IEC 60529	IP 65	
Weight	2100 g	

5 Technical data

Electrical data

Operating voltage VS	24 V DC ±20%
Ripple	≤ 10 %
Current draw at 24 V DC	≤ 1 A
X2, X3 – application interfaces	PROFINET
X4 - service interface	RS232
Characteristic impedance of the antenna ports	50 Ω

Operating frequency and radiated power

BIS U-6028-048-104-06-ST22, BIS U-6028-048-104-06-ST28

Operating frequency	865868 MHz	
Maximum permissible radiated power (ERP)	2 watt _{ERP}	
Number of used channels	4	
	ETSI channels: 4, 7, 10, 13	
Channel selection process Manual (channel assignment diagram)		

BIS U-6028-048-114-06-ST28

Operating frequency	902928 MHz
Maximum permissible radiated power (EIRP)	4 watt _{EIRP}
Number of used channels	52
Channel selection process	Automatic (frequency hopping method)

BIS U-6028-048-124-06-ST28

Operating frequency	920,5924,5 MHz	
Maximum permissible radiated power (EIRP)	2 watt _{EIRP}	
Number of used channels	16	
Channel selection process	Automatic (frequency hopping method)	

BIS U-6028-048-134-06-ST28

Operating frequency	915928 MHz
Maximum permissible radiated power (EIRP)	4 watt _{EIRP}
Number of used channels	26
Channel selection process	Automatic (frequency hopping method)

Operating conditions

Ambient temperature	-20 °C+55 °C
Storage temperature	−20 °C…+60 °C
EMC (Europe only) IEC 61000-6-2* ETSI EN 301 489 -1 / -3: - Severity level as per EN 61000-4-2/3/4/5/6 - RF emission as per EN 55022	 2B/3A/DC supply lines 3B, signal lines 4B/2B/3A Size 1, Cl. A
Vibration/shock	EN 60068 Part 2-2-6/27/29/32

5 Technical data

* Frequency band exempt from the test: 440 MHz to 465 MHz	
This UHF system consists of a processor and antennas as outlined in the specifications and ma	y
only be operated in industrial environments and only in the listed countries issuing operating	
licenses, subject to all applicable national legal regulations and standards.	
(see Chapter 2 "Safety" beginning on page 5).	

Data carriers	ISO 18000-6	Туре С	
	EPCglobal™	Class 1 Generation 2	

Multi-tagging

Configured EPC length	Maximum number of data carriers (Sum of all active antennas)
96 Bit	25 data carriers
496 Bit	15 data carriers



Note

Multitagging operation is supported starting with device software version 1.2 (see part label).

Function indicators

Operating states	Ready	Green LED
	Fault	Red LED
	Tag Present	Yellow LED
	Tag Operating	Yellow LED
	LNK1, LNK2	Yellow LED
	ACT1, ACT2	Yellow LED
	STA	Yellow LED
	BF	Yellow LED

• Bus connection

6.1	Project planning	During the project planning of fieldbus devices, a physical device is mapped as a modular system consisting of a head module and multiple data modules. The device data needed for project planning are stored in GSD files (General-Station-Description) in GSDML format (General Station Description Markup Language).						
	GSD file	The GSDML file for the BIS U-6028 can be downloaded from the BALLUFF website. The data modules of an IO-Link device are represented in the project planning software by slot. The GSDML file provides the possible data modules (inputs or outputs of various data width). For the configuration of an IO-Link device, the appropriate data modules are assigned to a particular slot.						
	Data modules	Input and output modules of 8 bytes, 16 bytes, 32 bytes, 64 bytes, 128 bytes and 254 bytes can be configured.						
	Integration in project planning software	 Project planning is performed, e.g., with the "SIMATIC NCM PC Manager" or "STEP 7" project planning tools. The following steps are generally necessary for integrating a BIS U-6028 processor: Install the GSDML file of the IO device in the hardware configuration Update catalog Use "Insert object" to add the "BIS U-6028_RT" IO device. Insert the two modules for inputs and outputs (e.g. "RT 32 Byte I" and "RT 32 Byte O" for the "BIS U-6028_RT" processor) Additional project planning steps: The name suffix "RT" or "IRT" indicates how the read and write data is exchanged. 						
		Note The processor has a two-port IRT switch and is therefore able to pass IRT data packets.						
		The object properties of the modules can be used to set the start addresses of the input and output data.						
		Note The input and output data can be used to control the BIS U-6028 as described in Chapter "Device function" on page 27.						
6.2	Device name and IP address	The object properties of the inserted object "u-6028" can be used to assign the device name, the device number and the IP address.						
		The processor and the host system communicate via the PROFINET protocol. This means an IP address and a unique device name are required. The device name and IP address can be saved in the IO device using "Target system > Ethernet > Edit Ethernet device".						
		Note The BIS U-6028 processor is shipped without a device name. In the included GSDML file, the device name "u-6028" is preset.						

The configuration of the processor is divided into two parts. One part is the configuration of the BUS parameters. The other is the configuration of the application parameters. The BUS parameters are configured directly via PROFINET and describe the behavior of the PROFINET interface, see Chapter "BUS parameters" on page 17 The application parameters are configured via the service interface (RS232) and specify the behavior of the processor with respect to the application, see Chapter "Application parameters" on page 19

7.1 BUS parameters

7

Basic knowledge	Schematic structure of the total buffer (process data)						
	Buffer 1 (for antenna 1 or antenna 3)						
	Buffer 2 (for antenna 2 or antenna 4)						
Dynamic mode	If the dynamic mode function (Dynamic) is enabled, the evaluation unit accepts the read/write job from the controlling system and saves it, regardless of whether a data carrier is in the active range of the antenna. If a data carrier enters the active range of the antenna, the stored job is run.						
Antenna number	If this parameter is activated, the antenna number of the currently selected antenna is displayed in the bit header.						
Parameter configuration	The configuration is performed during project planning/integration using a project planning software program such as "SIMATIC NCM PC Manager" or "STEP 7". Alternately, the configuration bytes can be sent directly using the controller. The parameters for operating the processor are stored in the GSDML file.						
	GSDML file The GSDML file contains all the device parameters for the processor.						
	Parameter overview						
	 Dynamic 1/2: If dynamic mode is configured, a read/write job can be sent even though no data carrier is present in the active range of the antenna. If a data carrier now arrives at the antenna, the command is immediately executed (saves time). Buffer 1: 						
	 This value indicates how many bytes of the entire input and output buffer should be used for buffer 1. The remainder of the input and output buffer is then available for buffer 2. ShowAntenna: 						
	If this is configured, the selected antenna (1 or 3 in buffer 1 or 2 or 4 in buffer 2) in the bit header of the respective buffer is displayed.						

Configuring the processor

Parameter configuration during project planning

7

The project planning software (e.g. "SIMATIC NCM PC Manager" or "STEP 7") can be used to configure the processor in the hardware configuration.

To do this, the added IO device is selected and the object properties opened by right-clicking "u-6028" on slot 0:



The "Parameters" tab is used to open the selection window for parameters:

Eige	enschaften - u-60x8 (R-/S0)		— ×
A	Ilgemein Adressen Parameter		
		Wert	
	🖃 🔄 Parameter		
	🗄 🔄 General parameters		
	—		
	– 📰 Dynamic 1		
	- Dynamic 2		
	Buffer 1	16	

7

7.2	Applications parameters	
	Default settings	The device is preset ex works. The default settings are highlighted for the respective parameters.
		Some parameters are fixed and cannot be modified:
		 Multiplexing: The multiplexing sequence and the dwell time in front of each antenna are fixed. The sequence in which the antennas are activated is always 1-2-3-4-1-2
	Configuration software	Configuration is performed using the "BIS UHF Manager" software. One requirement is that the processor is connected to the controlling system via the service interface (RS232). The configuration can be overwritten at any time. The parameters can be saved in an XML file so that they can be retrieved whenever needed.
		Note Detailed information on the "BIS UHF Manager" can be found in the software's online help system.
		 Start "BIS UHF Manager". Click "Device Settings" and "Parameters" in the menu bar. ⇒ The "Parameters" window appears.



Only the parameters listed in the following sections can be modified. The area for configuring advanced device parameters is password-protected and can only be accessed by a Balluff service technician.



- ► Start "BIS UHF Manager".
 - ⇒ If "Connect on startup" was selected in the "Interface Settings" window (factory setting), the device automatically attempts to establish the last identified connection.

If the device is able to establish the last identified connection, "BIS connected..." appears in the status bar.

If the device is not able to establish a connection, "BIS not connected..." appears in the status bar.

The device must then be connected manually:

- ► Click "Program settings" and "Interface" in the menu bar.
 - \Rightarrow The "Interface Settings" window opens.

7

Interface settings Service interface	Interface Settings	
(RS232)		BIS UHF ← Configuration Tool V1.0
	RS232 TCP / IP	
	RS232 Information	
	Port COM1	Baud rate: 115200 Data bits: 8 Search
		Parity: None
	Connect	
	Connect	
	Connect on startup	Close

When the program starts, the device automatically connects if "Connect on startup" was selected

in the "Interface Settings" window (factory setting).

When the "Interface Settings" window is opened, the last identified connection is displayed and the bar above the "Search" button is highlighted yellow.

- ► Click the "Search" button.
 - \Rightarrow The program searches for connections.

If the program finds a connection, the connection settings are displayed and the bar above the "Search" button is highlighted green.

- ► Click the "Connect" button.
 - \Rightarrow The device is connected.

If the program does not find a connection, the bar above the "Search" button is highlighted red.

Device Settings	Parameters Device Settings Tran	smit Power Read - Write	Configuration	BIS UHF Tool V1.0
	Carrier follow-up time (s)	one time		
	128	R-	eads	
	2 4 □ 7	□ 10 □ 13		
	Send To BIS Retrieve From BIS	Sav	e as	Close Load Defaults

Carrier follow-up time

Follow-up time in seconds of the switched-on antennas after the command is sent. The read or write command should be executed within this time after it is detected.

Default setting: 5 seconds

Max. number of tags at the same time Maximum number of data carriers expected in the field.

Default setting: 128

Environment

Factor rereadings (only for asynchronous detection or dynamic mode)

Number of rereadings after which a data carrier is reported as present (tag coming) or number of failed rereadings after which a data carrier is reported as not present (tag going) (only in dynamic mode).

Default setting: 5

ETSI channels

The channel setting determines the channel assignment. If multiple channels are activated, these are automatically selected by the device by means of the frequency hopping method.

Default setting: channel 4 switched on, channels 7...13 switched off



Note

The ETSI channels selection is only available when using the devices within the European Community.





Note

The *Gain* and *Loss* parameters are defined in the *Antenna type* and *Cable type* fields. These values are used to determine the maximum permissible radiated power.

The maximum permissible radiated power and factory settings differ depending on the set country profile. For information on the valid regulations of the different countries, see Chapter 2 "Safety".

In the countries of the European Union, the radiated power is specified in the form of an ERP power (max. 2 watt_{ERP}).

In the USA, Canada and Brazil, the radiated power is specified in the form of an EIRP power (max. 4 watt_{_{\rm FIRP}}).

See the "Basic UHF manual" for more information on radiated powers.

Configuring the processor

Enabled: Enables/disables antennas 1...4.

Default setting: antenna 1 enabled, antennas 2...4 disabled.

Antenna type Selection of the used antenna.

Default setting: BIS U-302-C1 or BIS U-302-C0

Port power For selecting the power on the device (socket power).

Default setting: 22.5 dBm (176 mW) or 20.5 dBm (112 mW)

Antenna power Power at the antenna (EIRP or ERP).

Default setting: 27 dBm (500 mW)

Cable type Selection of the used cable.

Default setting: BIS U-500-EF-05

7

Read - Write	Parameters	
	BIS Configuration Too	
	Device Settings Transmit Power Read - Write Interface	
	Tag Field Lengths	
	User data start address User data length (bytes)	
	TID length (bytes)	
	EPC length (bits) Epc96	
	Filtering	
	 Keep identical records in scan results 	
	C Eliminate identical records in scan results	
	Send To BIS Save as	Close
	Retrieve From BIS Open	ad Defaults

Tag Field Lengths area

User data start address

Start address of the USER data for automatic reading during data carrier searches and if USER data is used as an address during reading or writing.

Default setting: 0 bytes

User data length

Length of the USER data for automatic reading during data carrier searches and if USER data is used as an address during reading or writing. The value range is 1 to 16.

Default setting: 16 bytes

TID length Length of the TID data with value range from 2 to 12.

Default setting: 12 bytes



If data carriers have a length other than the TID set here, it is possible that they cannot be read from or written to.

Configuring the processor

EPC length

Length of the EPC format on the data carriers. This parameter determines the maximum length of the EPC data to be processed and the output format for the command "Read multiple data carriers (EPC)".

Default setting: 96 bits



If the actual EPC length of the data carriers is not equivalent to 96 bits, set the value to 496 bits. Otherwise the read and write commands cannot be run without errors.

8.1 Function Two buffers are needed to exchange data and commands between the processor and the host principle of the system. The buffer contents are exchanged using cyclical polling. The buffer content depends on **BIS U-6028** the cycle in which it is written (e.g. control commands at the beginning of a job). When writing the buffer, the sent data from the preceding cycle are overwritten. Unwritten bytes are not deleted and retain their data content. **Total buffer** The buffer size of the total buffer corresponds to the plugged-in RT module. Allocation of this total buffer over the two antennas is performed using the "Buffer 1" parameter. To be able to read or write the USER data, a buffer size of at least 9 bytes is needed. Example: If a total buffer of 16 bytes is selected and the "Buffer 1" (Antenna 1/3) parameter is set to 10 bytes, 6 bytes then remain for antenna 2/4. Two bytes less per antenna are available for data exchange, since the first and last byte of the respective data buffer is used for control and for status messages.

Output buffer The control commands for the identification system and the data to be written to the data carrier are sent via the output buffer.

Bit no. Subaddress	7	6	5	4	3	2	1	0
00 _{hex} = 1st bit header		TI	KA	HD		GR		AV
01 _{hex}	Command designator or data							
02 _{hex}		Start address (Low Byte) or data or number of bytes						
03 _{hex}	Start address (Middle Byte) or data							
04 _{hex}		Start address (High Byte) or data						
05 _{hex}		Number of bytes (Low Byte) or data						
06 _{hex}		I	Number c	of bytes (N	/liddle Byt	e) or data	a	
07 _{hex}	Number of bytes (High Byte) or data							
	Data							
Last byte = 2nd bit header		TI	KA	HD		GR		AV

8

Output buffer (continued)

Configuration and explanation (output buffer)

Subaddress	Bit name	Meaning	Function description		
00 _{hex} = bit header	ΤI	Toggle-bit in	Controller is ready to receive additional data (read job).		
	KA	Antenna deactivation	Activates or deactivates the antenna selected with HD. 0: activated 1: deactivated		
	HD	Antenna selection	Selection of the antennas for buffer 1 and buffer 2.		
			Buffer 1Buffer 20: antenna 10: antenna 21: antenna 31: antenna 4		
	GR	Ground state	The processor goes into base state for the respective antenna. Any pending job is canceled.		
	AV	Job	A job is pending for the respective antenna.		

Command d

The device software (see part label) supports the following command IDs:

esignators	
------------	--

Command	Command designator	Until software version 1.1	Software version 1.2 and later
No command	00 _{hex}	Yes	Yes*
Read data carrier (USER data)	01 _{hex}	Yes	Yes
	81 _{hex}	No	Yes*
Read EPC	03 _{hex}	Yes	Yes
	42 _{hex}	No	Yes*
Read TID	05 _{hex}	Yes	Yes
	44 _{hex} -	No	Yes*
Write data carrier (USER data)	02 _{hex}	Yes	Yes
	82 _{hex}	No	Yes*
Write EPC	04 _{hex}	Yes	Yes
	43 _{hex} -	No	Yes*
Write constant value (USER data)	32 _{hex}	Yes	Yes
	B2 _{hex}	No	Yes*
Set antenna power	45 _{hex} -	No	Yes*
Read out antenna power	46 _{hex} -	No	Yes*
Read multiple data carriers (EPC)	47 _{hex} -	No	Yes*
Read number of tags	55 _{hex} -	No	Yes*
Select (select data carrier)	40 _{hex} -	No	Yes*
Unselect (unselect)	41 _{hex} -	No	Yes*

* This command ID is recommended for new systems since it is compatible with other BIS product families.

Input buffer

The input buffer is used to send the data read by the identification system, the designations and the status codes to the controlling system.

Bit No. Subaddress	7	6	5	4	3	2	1	0
$00_{hex} = 1$ st bit string	BB	HF	ТО	AN	AF	AE	AA	TP
01 _{hex}	S	Status code or Data						
02 _{hex}		Data						
		Data						
Last byte = 2nd bit string	BB	HF	ТО	AN	AF	AE	AA	TP

Configuration and explanation (input buffer)

Subaddress	Bit name	Meaning	Function description
00 _{hex} =	BB	Ready	Processor unit is ready for operation.
bit string	HF	Antenna error	Cable breakage at antenna or no antenna connected.
	ТО	Toggle bit out	Read operation: additional data is made available by the processor unit. Write operation: processor unit can accept additional data.
	AN	Antenna	Selected antenna.
			Buffer 1Buffer 20: antenna 10: antenna 21: antenna 31: antenna 4
	AF	Job error	Error in processing the job or job canceled.
	AE	Job end	Confirmation – Job finished without error.
	AA	Job start	Confirmation – Job was recognized and started.
	TP	Tag present	Data carrier is in the range of the antenna (only in connection with read, write and list commands).

8

Input buffer (continued)

Structure of the input buffer

The process data buffer is identical for all commands.

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Status code or data	 If AF bit 1: provides information on the status of a query If AF bit 0: data is written as with the individual commands
	Data	If AF bit 1: unusedIf AF bit 0: data
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

Information

- The status code is only sent if the AF bit is set in the bit string.
- Because the read EPC can have varying lengths (number of bytes), a length field is sent. The maximum processed EPC length (12 bytes or 62 bytes) is configured.
- The TID is always sent in a 12-byte frame. The actual length within this frame is configured (see Chapter "BUS Parameters", page 17 and Chapter "Application Parameters", page 19).

Status codes

Information

Status codes are only valid in combination with the AF bit!

Subaddress	Function description
01 _{hex}	Job cannot be executed because there is no active data carrier in the active range of the antenna.
02 _{hex}	Not possible to read the data carrier.
03 _{hex}	Data carrier was removed from the range of the antenna during reading.
04 _{hex}	Cannot write to the data carrier.
05 _{hex}	Data carrier was removed from the range of the antenna during writing.
07 _{hex}	No or invalid command designator with set AV bit or the number of bytes is $00_{\rm hex}$.
09 _{hex}	Cable breakage at antenna or no antenna connected.
OE _{hex}	There is more than 1 data carrier or more than 1 selected data carrier in the active range of the antenna and the executed command is valid only for individual data carriers.
0F _{hex}	First and second bit string not equal. The second bit string must be used.
43 _{hex}	Error when reading or writing parameters of the internal memory.
44 _{hex}	Arbitrary device behavior.
46 _{hex}	Command outside the address range of the data carrier.
4E _{hex}	No antenna activated.

30 | BALLUFF

Communication

Communication between the controlling system and processor unit is defined by a sequence protocol. Communication between the controlling system and processor unit is implemented using control bit in the output and input buffer.

Basic sequence

- 1. The controller sends a command designator to the processor unit in the output buffer with the AV bit set. The AV bit tells the processor unit that a job is beginning and the transmitted data is valid.
- 2. The processor unit accepts the job and confirms the job by setting the AA bit in the input buffer.
- 3. If additional data needs to be exchanged for the job, readiness for additional data exchange is indicated by inverting the TI and TO toggle bits.
- 4. The processor unit has correctly executed the job and sets the AE bit in the input buffer.
- 5. The controller has accepted all data. The AV bit in the output buffer is reset.
- 6. The processor unit resets all control bits set in the input buffer during the job (AA bit, AE bit). The processor unit is ready for the next job.

Structure of the output buffer for various commands

Command designator 00_{hex}: No command present

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Command designa- tor	00 _{hex} : No command present.
	None	No meaning
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

Command designator 81_{hex} or 01_{hex}: Read individual data carrier (USER data)

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Command designator	81 _{hex} : read data carrier (USER data).
02 _{hex}	Start address 1 (Low Byte)	Start address (Low Byte) from which reading is to start.
03 _{hex}	Start address 2 (Middle Byte)	Start address (Middle Byte) from which reading is to start.
04 _{hex}	Start address 3 (High Byte)	Start address (High Byte) from which reading is to start.
05 _{hex}	Number of bytes 1 (Low Byte)	The number of bytes (Low Byte) that are to be read starting from the start address.
06 _{hex}	Number of bytes 2 (Middle Byte)	The number of bytes (Middle Byte) that are to be read starting from the start address.
07 _{hex}	Number of bytes 3 (High Byte)	The number of bytes (High Byte) that are to be read starting from the start address.
	None	No meaning
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

Command description (continued) If execution is successful, the response is passed to the input buffer in the following format:

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Data	Transmission of data that was read from the data carrier.
	Data	Transmission of data that was read from the data carrier. is continued, if necessary, in further buffer transmissi- ons until the total number of bytes is reached.
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

Command designator 42_{hex} or 03_{hex} : Read individual data carrier (EPC)

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Command designator	03 _{hex} : Read data carrier (EPC).
	None	No meaning
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

If execution is successful, the response is passed to the input buffer in the following format:

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Data	Number of bytes of the EPC read
	Data	Transmission of EPC data that was read from the data carrier. is continued, if necessary, in further buffer transmissions until the total number of bytes is reached.
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

Command description (continued)

Command designator 44_{hex} or 05_{hex} : Read individual data carrier (TID)

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Command designa- tor	05 _{hex} : read data carrier (TID).
	None	No meaning
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

If execution is successful, the response is passed to the input buffer in the following format:

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Data	Transmission of TID data that was read from the data carrier.
	Data	Transmission of TID data that was read from the data carrier. is continued, if necessary, in further buffer transmissions until the total number of bytes is reached.
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

Command description (continued)

Command designator 82_{hex} or 02_{hex} : Write to individual data carrier (USER data)

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Command designa- tor	82 _{nex} : Write to data carrier (USER data).
02 _{hex}	Start address 1 (Low Byte)	Start address (Low Byte) from which writing is to start.
03 _{hex}	Start address 2 (Middle Byte)	Start address (Middle Byte) from which writing is to start.
04 _{hex}	Start address 3 (High Byte)	Start address (High Byte) from which writing is to start.
05 _{hex}	Number of bytes 1 (Low Byte)	The number of bytes that are to be written starting from the start address (Low Byte).
06 _{hex}	Number of bytes 2 (Middle Byte)	The number of bytes that are to be written starting from the start address Middle Byte).
07 _{hex}	Number of bytes 3 (High Byte)	The number of bytes that are to be written starting from the start address (High Byte).
	None	No meaning
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

Data is accepted from the processor unit only after the command has been accepted by the processor unit and acknowledged.

00 _{hex}	1st bit string	
01 _{hex}	Data	Transmission of the data that is to be written to the data carrier.
	Data	Transmission of the data that is to be written to the data carrier.
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

Command description (continued)

Command designator 43_{hex} or 04_{hex} : Write to individual data carrier (EPC)

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Command designator	04 _{hex} : Write to data carrier (EPC).
02 _{hex}	No. of bytes	Number of bytes (162) to be written beginning with the start address 00_{hex} .
	None	No meaning
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

Data is accepted from the processor unit only after the command has been accepted by the processor unit and acknowledged.

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Data	Transmission of the data that is to be written to the data carrier.
	Data	Transmission of the data that is to be written to the data carrier.
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

Command designator ${\rm B2}_{\rm hex}$ or ${\rm 32}_{\rm hex}$: Write constant value to individual data carrier (USER data)

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Command designator	B2 _{hex} : Write to data carrier (USER data).
02 _{hex}	Start address 1 (Low Byte)	Start address (Low Byte) from which writing is to start.
03 _{hex}	Start address 2 (Middle Byte)	Start address (Middle Byte) from which writing is to start.
04 _{hex}	Start address 3 (High Byte)	Start address (High Byte) from which writing is to start.
05 _{hex}	Number of bytes 1 (Low Byte)	The number of bytes that are to be written starting from the start address (Low Byte).
06 _{hex}	Number of bytes 2 (Middle Byte)	The number of bytes that are to be written starting from the start address Middle Byte).
07 _{hex}	Number of bytes 3 (High Byte)	The number of bytes that are to be written starting from the start address (High Byte).
	None	No meaning
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

Data is accepted from the processor unit only after the command has been accepted by the processor unit and acknowledged.

00 _{hex}	1st bit string	
01 _{hex}	Data	Value that is to be written to the data carrier.
	None	No meaning
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

Command description (continued)

Command designator 45_{hex}: Set antenna power

	- nex	-
Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Command designa- tor	45 _{hex} : Set antenna power
02 _{hex}	Antenna power	Antenna power for the current antenna (head) in incre- ments of 0.25 dBm Permitted value range (decimal): BIS U-6028-048-104: 68 (+17.00 dBm ERP)132 (+33.00 dBm ERP) BIS U-6028-048-114 and BIS U-6028-048-134: 77 (+19.25 dBm EIRP)144 (+36.00 dBm EIRP) The set power is not permanently saved and is reset to the saved default value when the reader is booted. The socket power on the device is calculated and set based on the configured antenna/cable parameters.
	None	No meaning
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

Command designator 46_{hex}: Read out antenna power

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Command designa- tor	46 _{nex} : Read out antenna power
	None	No meaning
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

If execution is successful, the response is passed to the input buffer in the following format:

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Antenna power	Antenna power for the current antenna (head) in incre- ments of 0.25 dBm or 0 for antenna that is switched off
	None	No meaning
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

Command description (continued)

Command designator 47_{hex} : Read multiple data carriers (EPC)

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Command designa- tor	47 _{hex} : Read multiple data carriers (EPC)
02 _{hex}	Туре	0 = EPC (other values currently not supported)
03 _{hex}	Max Number of Data Carriers	Maximum number of data carriers to be output 1255, (0 = no limitation) If the number is greater than the values listed under ""Multi-tagging" on page 13", then the lower value applies.
	None	No meaning
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

If execution is successful, the response is passed to the input buffer in the following format:

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Number of data carriers read	1255
02 _{hex}	Number of bytes per EPC	12 or 64 This corresponds to the length of the longest transmitted EPC configured in the device. EPCs shorter than this length are output right-justified and filled with zeros on the left. In the following, the (number of data carriers read) × (number of bytes per EPC) are transmitted. For 64 bytes per EPC, the actual EPC length in ASCII is specified in the 1st and 2nd byte of the EPC.
03 _{hex}	Data of 1st EPC	Actual EPC data
	Data of 1st EPC	Actual EPC data
	Data of 1st EPC	Actual EPC data
	Data of 2nd EPC	Actual EPC data
	Data of 2nd EPC	Actual EPC data
	Data	is continued, if necessary, in further buffer transmissions until the total number of bytes is reached.
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

This command always responds immediately—even for configured dynamic mode—with the currently identified number of tags.

If no tag is identified, this command generates an error message (status code 01).

Command description (continued)

Command designator $\mathbf{55}_{\mathrm{hex}}$: Read number of tags

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Command designa- tor	55 _{hex} : Read number of tags
	None	No meaning
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

If execution is successful, the response is passed to the input buffer in the following format:

Subaddraaa	Mooning	Eurotion departmention
Subaduress	wearing	Function description
00 _{hex}	1st bit string	
01 _{hex}	Number of data carriers read	0255
	None	No meaning
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

This command always responds immediately—even for configured dynamic mode—with the currently identified number of tags.

If no tag is identified, this command returns the number "0" and no error message.

Command description (continued)

Command designator 40_{hex}: Select (data carrier selection for multi-tagging)

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Command designa- tor	40 _{hex} : Select tag (selection of the data carrier to be used for further processing steps such as reading or writing)
02 _{hex}	Туре	0 = EPC (other values currently not supported)
03 _{hex}	No. of bytes	Number of bytes of the data carrier identifier (EPC) that is transmitted in following cycles.
04 _{hex}	Reserved	Reserved for expansions; please set to 0.
05 _{hex}	Reserved	Reserved for expansions; please set to 0.
06 _{hex}	Reserved	Reserved for expansions; please set to 0.
	None	No meaning
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

Data of the data carrier identifier is accepted from the processor unit only after the command has been accepted by the processor unit and acknowledged.

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Data	1st byte of the data carrier identifier (EPC or TID)
	Data	Other bytes of the data carrier identifier (EPC or TID) is continued, if necessary, in further buffer transmissi- ons until the total number of bytes is reached.
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

After the Select command, read/write commands (command designators 01_{hex} , 02_{hex} , 03_{hex} , 04_{hex} , 05_{hex} , 32_{hex} , 42_{hex} , 43_{hex} , 44_{hex} , 81_{hex} , 82_{hex} , $B2_{hex}$) for the corresponding antenna are run only on the designated data carrier, if it is available.

If the selected data carrier is not in the field of the antenna at the moment, the Select command is processed without errors anyway, but following read/write commands return an error with status code 01_{hex} (no data carrier).

If the selected data carrier identifier is present on more than one tag, the following commands are run as follows:

- Read commands are run on **one** data carrier, which is randomly selected from the suitable data carriers.
- Write commands are run on **all** suitable data carriers.

Command	Information
description (continued)	 The data carrier identifier is usually taken from a preceding command 47_{hex}: <i>Read multiple data carriers (EPC)</i>. Omit the leading fill bytes in the data carrier list for this. The entire entry is usually used for the 12-byte EPC format; for the 64-byte format (as ASCII digits in byte address 0 and 1 of the respective entry), read the actual length and then read out the identifier starting from the byte address (64-length). Example: Length specification = "24" means that the EPC is in byte address 4063.
	 If multiple data carriers are to be processed in sequence, what usually results is the following command sequence:
	Command 47 _{hex} : Read multiple data carriers (EPC)
	Command 40 _{nex} : Select (1st identifier) Process 1st data carrier
	Command 40 _{hex} : Select (2nd identifier) Process 2nd data carrier
	Command 40 _{hex} : Select (3rd identifier) Process 3rd data carrier
	etc.
	Command 41 _{hex} : Unselect
	The controller can choose the sequence of data carriers at random, omit data carriers or select the same one repeatedly.
	With the BIS U-602_ devices the selection is made only using the EPC, thereby also enabling operation of multiple antennas at one read position. Then a data carrier with a suitable data carrier identifier is also read if it is located in front of an antenna other than the one to which the Select command refers. If you need to ensure that only data carriers in front of the current antenna are read after a Select command, the EPC identifiers of the data carrier must be unique and the presence of the data carrier in front of the desired antenna must first be checked using command 47 _{hex} : <i>Read multiple data carriers (EPC)</i> .
	 A data carrier selection for an antenna remains valid until one of the following events occurs: A new selection is defined. An Unselect command undoes the selection. The GR bit (basic state) for the corresponding antenna is set. The device is restarted.

Command description (continued)

Command designator 41_{hex} : Unselect (undo the data carrier selection)

Subaddress	Meaning	Function description
00 _{hex}	1st bit string	
01 _{hex}	Command designa- tor	41 _{hex} : Unselect (undo the fixed data carrier selection)
	None	No meaning
Last byte	2nd bit string	If first and second bit strings agree, there is valid data present.

The Unselect command undoes a data carrier selection for an antenna. If no selection was made, the status remains unchanged.

Subsequent read/write commands then refer to any individual data carrier in the field of the antenna. If multiple data carriers are in the field of the antenna, the following read/write commands are ended with an error and status code OE_{hex} (multiple data carriers).

Bevice function

8.2 Function The operating states of the identification system and the PROFINET connection are indicated via LEDs.



Fig. 7: Function indicators

- Identification system
- 1 Ready/Error
- 2 Bus Failure (BF)
- 3 Tag Operating
- 4 Tag Present5 Port 2 Activity (ACT2)

6 Port 2 Link (LNK2)

- 7 Port 1 Link (LNK1)
 - 8 Port 1 Activity (ACT1)
 - 9 Status (STA)
- Start-up phaseThe "Ready/Error" LED flashes green during the start-up phase.
When setup is finished and the system is ready for operation, the "Ready/Error" LED lights up
green.

Diagnostics

Identification system

Status LED	Meaning
Ready / Error	
Off	Device is not ready for operation
Green, lit	Device is ready for operation
Green, flashing	Startup phase of the device (Setup)
Red, flashing	Error (e.g. device error or broken cable)

Tag operating	
Off	No command
Yellow, lit	Command to data carrier (e.g. detect, read or write)

Tag present	
Off	No command
Yellow, flashing	No data carrier detected in the active range of the antenna
Yellow, lit	Data carrier detected in the active range of the antenna

Ethernet and PROFINET connection

STA (Status)	
Off	PROFINET: not yet ready
Yellow, lit	PROFINET: ready

BF (Bus Failure)	
Off	PROFINET: connection established
Yellow, lit	PROFINET: no connection or configuration

LNK1 / LNK2 (Link)

()	
Off	Ethernet: no connection
Yellow, lit	Ethernet: connection OK
Yellow, flashing	DCP flashing activated

ACT1 / ACT2 (Activity)		
Off	Ethernet: no activity	
Yellow, lit	Ethernet: RX- / TX-activity	

Device function

8.3 Examples

1st example

Read 33 bytes of USER data starting at data carrier address 10

For configuration with 16-byte	Command from controller]	BI	S U-6028 reaction
buffer size!					
	1. Process (note see	output buffer quence):		2. Process input buffer: (note sequence):	
	01 _{hex}	Command designator 01 _{hex}		00 _{hex} /0F _{hex}	Set AA bit
	02 _{hex}	Start address 0A _{hex}	1	010E _{hex}	Enter first 14 bytes
	03 _{hex}	Start address 00 _{hex}]	00 _{hex} /0F _{hex}	Set AE bit
	04 _{hex}	Start address 00 _{hex}]		
	05 _{hex}	No. of bytes 21 _{hex}			
	06 _{hex}	No. of bytes 00 _{hex}			
	07 _{hex}	No. of bytes 00 _{hex}			
	00 _{hex} /0F _{hex}	Set AV bit			
	 Process input buffer: 010E_{hex} Copy first 14 bytes 			 4. Process input buffer: 010E_{hex} Enter second 14 bytes 	
	Process		1		Invert 10 bit
	00 _{hex} /0F _{hex}	Invert II bit			
	5. Process	input buffer:		6. Process i	nput buffer:
	010E _{hex}	Copy second 14 bytes		0105 _{hex}	Enter last 5 bytes
	Process	output buffer:	-	00 _{hex} /0F _{hex}	Invert TO bit
	$00_{hex}/0F_{hex}$	Invert TI bit			
	7. Process	input buffer:	AND	8. Process i	nput buffer:
	0105 _{bev}	Copy last 5 bytes		$00_{\rm hex}/0F_{\rm hex}$	Reset AA and AE bits
	Process output buffer:		-]
	00 _{hex} /0F _{hex}	Reset AV bit]		

2nd example

Read the EPC of the data carrier

For configuration
with buffer size of
16 bytes and
EPC length of
12 bytes!

Command from controller			BIS U-6028 reaction				
1. Process output buffer (note sequence):			2.	Process ir (note sequ	nput buffer: uence):		
01 _{hex}	Command designator 03 _{hex}		00,	"/0F _{hex}	Set AA bit		
00 _{hex} /0F _{hex}	Set AV bit		01 _{he}	Эх	Length of the received EPC		
		-	02.	0D _{hex}	Enter EPC		
			00,	,/0F _{hex}	Set AE bit		
		ANNANANANANANANANANANANANANANANANANANA					
3. Process i	nput buffer:		4.	Process in	nput buffer:		
020D _{hex}	Copy EPC		00	,/0F _{hex}	Reset AA and AE bits		
Process	output buffer:	_					
$00_{\rm hex}/0F_{\rm hex}$	Reset AV bit]					

B Device function

3rd example

Read the TID of the data carrier

For configuration with 16-byte buffer size! If the TID length configured in the UHF manager is shorter than 12 bytes, leading zeros are used to pad the TID to 12 bytes.

Comm			BIS	S U-6028 reaction	
1. Process (note sec	output buffer juence):	-	2.	Process ir (note seqi	nput buffer: uence):
01 _{hex}	Command designator 05 _{hex}		00,	_{ex} /0F _{hex}	Set AA bit
$00_{hex}/0F_{hex}$	Set AV bit		01.	0C _{hex}	Enter TID
			00,	_{ex} /0F _{hex}	Set AE bit
		ANNALAN MANALANA			
3. Process	nput buffer:		4.	Process ir	nput buffer:
010C _{hex}	Copy TID		01.	0F _{hex}	Reset AA and AE bits
Process	output buffer:				
00 _{hex} /0F _{hex}	Reset AV bit]			

```
4th example
```

Read 30 bytes of USER data starting at data carrier address 10 with read error

For configuration with 16-byte buffer size!

Information

i

00_{hex}/0F_{hex}

Set AV bit

l lf	an error occurs, the AF bit is set i rror number. Setting the AF bit ca	nstea ncels	id of the AE b the job and c	it, together with a corresponding leclares it as finished.				
Command from controller				515 0-6026 reaction				
1. Proce	ess output buffer		2. Process	s input buffer:				
(note	sequence):		(note sequence): If an error occurs immediately!					
01 _{hex}	Command designator 01 hex	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	00 _{hex} /0F _{hex}	Set AA bit				
02 _{hex}	Start address 0A _{hex}		01 _{hex}	Enter error number				
03 _{hex}	Start address 00 _{hex}		00 _{hex} /0F _{hex}	Set AF bit				
04 _{hex}	Start address 00 _{hex}			·				
05 _{hex}	No. of bytes 1E _{hex}							
06 _{hex}	No. of bytes 00 _{hex}							
07,	No. of bytes 00 _{box}							

3. Process i	nput buffer:	4.	Process ir	nput buffer:
01 _{hex}	Copy error number	00	/OF _{hex}	Reset AA and AF bits
Process of	output buffer:			
00, /0F,	Invert AV bit			

5th example	Write 32 byte	es of USER data starting a	data	carrier addres	s 20
For configuration	Comr	nand from controller		BI	S U-6028 reaction
with 16-byte buffer size!	1 Process	output buffor		2 Process i	pout huffor:
	(note sec	quence):		(note seq	uence):
	01 _{hex}	Command designator 02 _{he}	<u> </u>	$00_{hex}/0F_{hex}$	Set AA bit
	02 _{hex}	Start address 14 _{hex}	_		Invert TO bit
	03 _{hex}	Start address 00 _{hex}			
	04 _{hex}	Start address 00 _{hex}			
	05 _{hex}	No. of bytes 20 _{hex}			
	06 _{hex}	No. of bytes 00 _{hex}			
	07 _{hex}	No. of bytes 00 _{hex}			
	00 _{hex} /0F _{hex}	Set AV bit			
	3. Process	output buffer:		4. Process of	putput buffer:
	010E _{hex}	Enter first 14 bytes		010E _{hex}	Copy first 14 bytes
	$00_{hex}/0F_{hex}$	Invert TI bit		Process input	buffer:
				00 _{hex} /0F _{hex}	Invert TO bit
	5. Process	outout buffer:	ANNIN MANANANANANANANANANANANANANANANANANANA	6. Process	output buffer:
	010E	Enter second 14 bytes		010E	Copy second 14 bytes
	00, /0F,	Invert TI bit		Process input	buffer:
	L Hex Hex	1]	00 _{ho} /0F _{hox}	Invert TO bit
			MINIMUM MINIMUM		
	7. Process	output buffer:		8. Process	putput buffer:
	0104 _{hex}	Enter last 4 bytes		0104 _{hex}	Copy last 4 bytes
	00 _{hex} /0F _{hex}	Invert TI bit		Process input	buffer:
				00 _{hex} /0F _{hex}	Set AE bit
			ANNAL MARKET		
	9. Process	output buffer:		10. Process i	nput buffer:
	$00_{\rm hex}/0F_{\rm hex}$	Reset AV bit		$00_{\rm hex}/\rm{OF}_{\rm hex}$	Reset AA and AE bits

6th example

For configuration with 16-byte	Comn	nand from controller]	BI	S U-6028 reaction
buffer size!					
	1. Process (note sec	output buffer quence):		2. Process i (note seq	nput buffer: uence):
	01 _{hex}	Command designator 02 _{hex}		00 _{hex} /0F _{hex}	Set AA bit
	02 _{hex}	EPC length]		Invert TO bit
	00 _{hex} /0F _{hex}	Set AV bit			· · · · · ·
	7. Process	output buffer:		8. Process of	putput buffer:
	010C _{hex}	Enter EPC		010C _{hex}	Copy EPC
	00 _{hex} /0F _{hex}	Invert TI bit		Process input	buffer:
			_	00 _{hex} /0F _{hex}	Set AE bit
	9. Process	output buffer:	- Muhamanananananananananananananananananana	10. Process i	nput buffer:
	$00_{hex}/0F_{hex}$	Reset AV bit		00 _{hex} /0F _{hex}	Reset AA and AE bits

Write 12 bytes of EPC on the data carrier

Bevice function

7th example

Establish base state of antenna 1

For configuration with 16-byte buffer size! The antennas of the BIS U identification system can be set to the base state independent of one another.

Control	Identification system
1. Process output buffer (note sequence):	2. Go to base state. Process input buffer:
00 _{hex} /0F _{hex} Set GR bit	00 _{hex} /0F _{hex} Reset BB bit
 Process output buffer: 	4. Process input buffer:
00 _{hex} /0F _{hex} Reset GR bit	00 _{bex} /0F _{bex} Set BB bit

8th example	Switch off antennas
For configuration with 16-byte buffer size!	In normal operation, both antennas are switched on. By setting the KA bit, the antenna selected by the HD bit can be switched off (antenna 1 or 3 for buffer 1, antenna 2 or 4 for buffer 2).
	Control
	1. Process output buffer:
	00 _{hex} /0F _{hex} Set KA bit

The antennas are switched back on by resetting the KA bit.

9th example	Read the EP	Cs of multiple data carrier	s in fro	ont of the ante	nna				
For configuration with 16-byte	With a maximum number of 5, EPC size of 12 bytes configured, 3 data carriers identified								
buffer size!	Comr	mand from controller		BI	S U-6028 reaction				
	1. Process output buffer (note sequence):			2. Process input buffer (note sequence):					
	01 _{hex}	Command designator 47	×	00 _{bex} /0F _{bex}	Set AA bit				
	02 _{bex}	Type EPC 00 _{hev}	<u></u>	01 _{bex}	Number of data carriers 03 _{her}				
	03 _{hex}	Max. number 05 _{hex}		02 _{hex}	Number of bytes per EPC 0C _{hex}				
	00 _{hex} /0F _{hex}	Set AV bit		03 _{hex} 0E _{hex}	First EPC 12 bytes				
				00 _{hex} /0F _{hex}	Set AE bit				
	3a. Process	input buffer: Note number of data carriers		4. Process 010C _{hex}	input buffer: Enter second EPC 12 bytes				
	02 _{ber}	Save number of bytes		0D _{bey} /0E _{bey}	Enter third EPC 2 bytes				
	03 _{bex} /0E _{bex}	Copy first EPC 12 bytes		00 _{hex} /0F _{hex}	Invert TO bit				
	3b. Process	output buffer:]				
	00 _{hex} /0F _{hex}	Invert TI bit							
	5a Process	input buffer:		6 Process	input buffer.				
	01,0C	Copy second EPC		010A	Enter third EPC 10 bytes				
	nex nex	12 bytes		nex nex	,				
	$\rm OD_{hex}/OE_{hex}$	Copy third EPC 2 bytes		00 _{hex} /0F _{hex}	Invert TO bit				
	5b. Process	output buffer:	_						
	$00_{\rm hex}/0F_{\rm hex}$	Invert TI bit							
	7a. Process	input buffer:		8. Process	input buffer:				
	$01_{\rm hex}$ /0A_{\rm hex}	Copy third EPC 10 bytes		$00_{hex}/0F_{hex}$	Reset AA and AE bits				
	7b. Process	output buffer:							
	00 _{hex} /0F _{hex}	Reset AV bit							

B Device function

10th example	Select a data	carrier for further process	ing			
For configuration with 16-byte	For configurati	ion with EPC size of 12 bytes				
buffer size!	Comr	nand from controller]		BI	SU-6028 reaction
	1. Process (note sec	output buffer quence):		2. F (r	Process in note sequ	nput buffer uence):
	01 _{hex}	Command designator 40 _{hex}		00 _{hex} /0	0F _{hex}	Set AA bit
	02 _{hex}	Type EPC 00 _{hex}]			Invert TO bit
	03 _{hex}	Length of the EPC 0C _{hex}]			
	04 _{hex}	Reserved 00 _{hex}				
	05 _{hex}	Reserved 00 _{hex}				
	06 _{hex}	Reserved 00 _{hex}				
	$00_{hex}/0F_{hex}$	Set AV bit				
	3. Process	output buffer:		4a. F	Process of	output buffer:
	01 _{bex} 0C _{bex}	Enter 12 bytes EPC	innnun	01 _{bex} .	0C _{hex}	Save EPC
	00 _{hex} /0F _{hex}	Invert TI bit		4b.	Process	input buffer:
	<u> </u>	·	_	00 _{hex} /	0F _{hex}	Set AE bit
			HIMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMM	Who.		
	5. Process	output buffer:		6. F	Process ii	nput buffer:
	00 _{hex} /0F _{hex}	Reset AV bit		00 _{hex} /	0F _{hex}	Reset AA and AE bits

Appendix

Type code

BIS U- 6028 -048-104-06-ST28

Balluff identification system Series U read/write system Hardware type 6020 = Serial interface RS232 (metal housing) 6026 = EtherNet/IP (metal housing) 6027 = Ethernet TCP/IP (metal housing) 6028 = PROFINET (metal housing)	
Software type 034 = Balluff protocol EtherNet/IP 048 = Balluff protocol PROFINET 053 = Balluff protocol RS232 UHF for Europe 054 = Balluff protocol Ethernet TCP/IP UHF for Europe 059 = Balluff protocol RS232 UHF for USA/Canada/Mexico/Brazil/China/Japan etc. 060 = Balluff protocol Ethernet TCP/IP UHF for USA/Canada/Mexico/Brazil/China/Japan etc.	
Antenna socket version 10_ = Country setting 865868 MHz Europe 11_ = Country setting 902928 MHz USA/Canada/Mexico/Argentina 12_ = Country setting 920.5924.5 MHz China 13_ = Country setting 915928 MHz Brazil 15_ = Country setting 916.8920.4 MHz Japan 17_ = Country setting 920926 MHz Australia 4 = 4 antenna sockets	
Interface 00 = RS232 06 = Ethernet]
Customer connection ST22 = for PROFINET device with AIDA recommendation ST26 = for serial device ST27 = for TCP/IP device ST28 = for PROFINET device ST35 = for EtherNet/IP device	

Accessories (optional, not included in scope of delivery)

Туре

Mounting plates

Order designation

BIS Z-HW-004



You can find more accessories for the BIS U-6028-... in the Balluff BIS catalog and under www.balluff.com.

Appendix

ASCII table

Decimal	Hex	Control code	ASCII	Decimal	Hex	ASCII	Decimal	Hex	ASCII
0	00	Ctrl @	NUL	43	2B	+	86	56	V
1	01	Ctrl A	SOH	44	2C	,	87	57	W
2	02	Ctrl B	STX	45	2D	-	88	58	Х
3	03	Ctrl C	ETX	46	2E		89	59	Y
4	04	Ctrl D	EOT	47	2F	/	90	5 A	Z
5	05	Ctrl E	ENQ	48	30	0	91	5B	[
6	06	Ctrl F	ACK	49	31	1	92	5C	\
7	07	Ctrl G	BEL	50	32	2	93	5D	[
8	08	Ctrl H	BS	51	33	3	94	5E	^
9	09	Ctrl I	HT	52	34	4	95	5F	_
10	0 A	Ctrl J	LF	53	35	5	96	60	`
11	0B	Ctrl K	VT	54	36	6	97	61	А
12	0C	Ctrl L	FF	55	37	7	98	62	В
13	0D	Ctrl M	CR	56	38	8	99	63	С
14	0E	Ctrl N	SO	57	39	9	100	64	d
15	0F	Ctrl O	SI	58	3 A	:	101	65	е
16	10	Ctrl P	DLE	59	3B	;	102	66	f
17	11	Ctrl Q	DC1	60	3C	<	103	67	g
18	12	Ctrl R	DC2	61	3D	=	104	68	 h
19	13	Ctrl S	DC3	62	3E	>	105	69	i
20	14	Ctrl T	DC4	63	ЗF	?	106	6 A	i
21	15	Ctrl U	NAK	64	40	@	107	6B	k
22	16	Ctrl V	SYN	65	41	Α	108	6C	L
23	17	Ctrl W	ETB	66	42	В	109	6D	m
24	18	Ctrl X	CAN	67	43	C	110	6E	n
25	19	Ctrl Y	EM	68	44	D	111	6F	0
26	1 A	Ctrl Z	SUB	69	45	E	112	70	
27	1B	Ctrl [ESC	70	46	F	113	71	
28	1C	Ctrl \	FS	71	47	G	114	72	r
29	1D	Ctrl 1	GS	72	48	Н	115	73	S
30	1E	Ctrl ^	RS	73	49	1	116	74	t
31	1F	Ctrl	US	74	4 A	J	117	75	u
32	20		SP	75	4B	K	118	76	V
33	21		!	76	4C	L	119	77	W
34	22			77	4D	 M	120	78	X
35	23		#	78	4F	N	121	79	Y
36	24		\$	79	4F	0	122	7 A	7
37	25		%	80	50	P	123	7B	-
38	26		~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	81	51	0	124	70	
39	27		1	82	52	R	125	70	}
40	28		(83	53	S	120	7F	~
41	29)	84	54	т	127	7F	DEI
- 1	20		/	07			121		

Index

Α

Accessories 53 Areas of application 7 Assigning an IP address 20

В

BIS UHF Manager 20

С

Configuration software 19 Conformity 6 Control bit Ground state 28 Job 28 Toggle-bit in 28

D

Data carriers, approved 15 Data integrity 8 Dimensions 12, 13 Display elements Identification system 43

Е

Electrical connection 10, 11 Electrical data 14

F

Factory settings 19 Function indicators 15 Function principle 7, 27

I

Installation 9 Intended use 5 Interface Connection settings 20 Interface information 10, 11

Μ

Main components 7

Pin assignment 11 Product description 7

S

Safety Antennas 5 Installation 5 Minimum distance 5,9 Operation 6

Startup 5 Scope of delivery 9 Status indicators 42

Т

Technical data Electrical 14 Mechanical 12, 13 Operating conditions 14 Type code 53

U

UHF Manager 19 Start 20

www.balluff.com

Balluff GmbH Schurwaldstraße 9 73765 Neuhausen a.d.F. Germany Tel. +49 7158 173-0 Fax +49 7158 5010 balluff@balluff.de www.balluff.com