

Achtung !

Werden Leseköpfe **BIS L-30_-...** ab der Hardware V2.0 verwendet, so können diese ab der ersten Verwendung nur noch mit Auswerteeinheiten **BIS L-60__-...** ab der Software V2.0 betrieben werden.

Soll ein Lesekopf **BIS L-30_-...** ab der Hardware V2.0 wieder für die Verwendung an einer Auswerteeinheit **BIS L-60__-...** mit einer Software Version vor V2.0 betrieben werden, so gehen sie vor wie folgt:

- Parametrieren Sie eine Auswerteeinheit **BIS L-60__-...** ab Version V2.0 mit dem Parameter „Typ und Serial Number bei CT present“.
- Entfernen Sie nun den Kopf **BIS L-30_-...** . Dieser kann jetzt wieder an Auswerteeinheiten mit Software Version vor V2.0 betrieben werden

Note !

If read heads **BIS L-30** or higher are used, they will be operable after the first use only with **BIS L-60** processors having version V2.0 or higher.

To allow a **BIS L-30** read head hardware version V2.0 or higher to be used again with a **BIS L-60** processor having a software version earlier than V2.0, proceed as follows:

- Configure a **BIS L-60** processor V2.0 or higher with the parameter “Type and Serial Number for CT present”.
- Remove the **BIS L-30** read head. Now it may be used again with processors having a software version earlier than V2.0.