



Mounting Instructions:

1. Screw the Sensor into the holder until it bottoms out.
2. Thread the M30 nut on the sensor until it is flush with the holder and then tighten.
3. NOTE: Torque spec is max. 40 Nm
4. Attach the BCC cable.
5. NOTE: The sensor housing is equipped with magnets used to hold the housing together while the sensors are transmitting data.

